

## How to install Océ Repro Desk 4.25i

These instructions apply to the following Océ Repro Desk products:

- 9800/ 9700 Server
- 9400/ 9300 Server
- PS Out
- HPGL-2 Out

Instructions for installation of the Océ Repro Desk 9600 Server are available in a separate document.

### Work order alert

If you installed the 4.25 USA release, you will have to recustomize the work order for your Remote Client users after you install the 4.25i release.

### JAWS alert

If you are using JAWS, you may install the 4.25i release over 4.21 or 4.25USA. The PS/PDF interpreter files will be unaffected. However, if you wish to uninstall the previous version before you install 4.25i, then you must back up the following files and folders (with all their contents) and copy them into the 4.25i installation directory: jawsnt.dll, jawspm.exe, Font, Lib and Resource.

### Login alert

You must log into Windows NT with administrator privileges, including password, to use this method. Other 4.25i installation methods are not recommended.

### Get ready

Make sure you have the following:

- A hard drive with a C partition of at least 1 GB (2 GByte preferred).
- 128 MB SDRAM (256 MB recommended).
- Pentium II 333 MHz processor or higher. Celeron processors are not recommended.
- Microsoft Internet Explorer 5.0 (IE5) setup, available at <http://www.microsoft.com/downloads/search.asp?> or on the 4.25 USA CD, not on the 4.25i CD.
- Windows NT Service Pack 5 (SP5) setup, available at <http://www.microsoft.com/downloads/search.asp?> or on the 4.25 USA CD, not on the 4.25i CD.
- An Océ Repro Desk 4.25i CD.
- A hardcopy of the Install Keys for products you want to install.
- For new installations, have Windows NT (build 1381 recommended) installed on a C drive with at least 1 MB (2 MB preferred).
- For upgrades, a record of existing security codes.

Step 1: For upgrades, uninstall any previous versions of Repro Desk. For new installations, skip to Step 4.

- Step 2: Delete the Repro Desk installation directory (usually c:\ocerd).
- Step 3: In the WINNT directory, delete or rename job.ini, job.xml, and job.xml.bak.
- Step 4: If you have Windows NT Service Pack 4 or lower, install SP5.
- Step 5: Reboot.
- Step 6: If you have Microsoft Internet Explorer 4.0 or lower, install IE5.
- Step 7: Reboot.
- Step 8: Allow IE5 setup to finish.
- Step 9: Insert the Repro Desk installation CD and run setup.
- Step 10: In the Major Product dialog box, enter the key for the major product you want to install.
- Step 11: In the Minor Products dialog box, enter the key for any products you want to install.
- Step 12: In the Select a location for shortcuts dialog box, click **All Users Folder Group**.
- Step 13: In the ODBC notification message, click **OK**.
- Step 14: In the Setup Complete dialog box, click the **No, I will restart my computer later** radio button, then click **Finish**.
- Step 15: Launch Repro Desk.
- Step 16: In the Help menu, click **Security**. The Security dialog box appears.
- Step 17: For new installations, call Océ for Repro Desk security codes and type them in the appropriate fields. For upgrades, you can generally use the same codes you used in previous versions except for 9400 products. If you get new codes for one product, you must get new codes for all other products you are using. Do not mix codes issued for previous versions of Repro Desk with codes issued for 4.25i within the dialog box.
- Step 18: In the Security dialog box, click **OK**.
- Step 19: In the Configure menu, click **Defaults**. The Configuration dialog box appears.
- Step 20: Enter configuration information, such as accounting methods, pen path, and so on.

- Step 21: Close Repro Desk and shut off the printer.
- Step 22: Reboot.
- Step 23: If you will be using accounting, launch IE5. Internet Explorer may attempt to open a Microsoft Web page or tell you to install IE5.5 or higher the first time you launch it. Ignore these warnings, and close IE5.
- Step 24: Right-click the IE5 icon on your desktop. A menu appears.
- Step 25: Click **Properties**. The Properties dialog box appears.
- Step 26: Click the Security tab, and then click the Local Intranet icon. In the Security level for this zone section, click **Low**.
- Step 27: Click the General tab. In the Home Page section, type the URL for your default Web page.
- Step 28: Click **OK**.
- Step 29: Launch Repro Desk, then launch Print Manager.
- Step 30: Turn your printer on, and wait for it warm up. You should be up and running now.